


MONTAGEVOORSCHRIFT

MOUNTING INSTRUCTIONS


CR-A

MONTAGE - ANLEITUNG

INSTRUCTIONS DE MONTAGE





CR - A 8buizen






CR - A 10buizen

Werkdruk : Max. 10 bar
Betriebsdruck : Max. 10 bar
Pression de service : Max. 10 bar
Operating pressure : Max. 10 bar



CR - O 16buizen



CR - A 20buizen

